


MUL-17

Sealless Combination Tool for Steel Strapping

50, 53, 54	16 mm, 19 mm
82; 83; 86	15 mm, 20 mm



MUL-17 PART LIST

Sealless Combination Tool for Steel Strapping

No	KEYNo	Description	QTY
01	17-01	TENSION HANDLE	1
04	17-04	FRAME	1
05	17-05	SIDE COVER	1
06	17-06	BUSHING	1
07	16-07	STRAP LIFTER	2
08	16-08	PAWL SHAFT	2
09	16-09	GUIDE ARM PIN	2
10	16-10	SHOULDERED SCREW	1
11	17-11	GUIDE ARM	1
12	17-12	FEED WHEEL SUPPORT HANDLE	1
15	16-15	EXCENTRIC SHAFT	1
17	17-17	DIE HOLDER	1
18	16-18	CAM FOLLOWER	1
19	16-19	DIE HOLDER SHAFT	1
21	16-21	DIE	3
22	17-22	CUTTER BLADE	1
23	17-23	FEED WHEEL SUPPORT SHAFT	1
24	17-24	PIN 2,7x7	1
25	16-25	CLUTCH PLUG (BOTTOM GRIPPER)	1
26	16-26	FEED WHEEL	1
28	16-28	RETAINING PAWL , SHORT	1
29	16-29	PAWL SPRING	3
30	16-30	HANDLE PAWL	1
31	16-31	RATCHET WHEEL	1
32	17-32	FEED WHEEL SHAFT	1
33	17-33	PAWL HOLDER	1
34	16-34	RING	2
35	16-35	ADJUSTMENT PLATE	1
36	16-36	KNOB	2
37	16-37	FEED WHEEL SUPPORT SPRING	1
38	16-38	RETAINING PAWL, LONG	1
41	16-41	WASHER	2
43	16-43	PIN 3x22	2
45	16-45	WASHER	1
49	17-49	ROD	1
50	16-50	STRAP GUIDE PAWL, 16 – 19	1
51	17-51	SCREW	1
53	16-53	STRAP GUIDE, FRONT, 16 – 19	1
54	17-54	STRAP GUIDE, REAR, 16 - 19	2
57	15-57	SCREW M4X8	2
58	15-58	SCREW M4X12	5
60	16-60	SCREW M6X10	1
61	15-61	SCREW M6X14	3
62	15-62	SCREW M4X10	3
63	15-63	SCREW M8X14	1
64	17-64	SCREW M4X6	1
66	16-66	NUT M6	2
67	16-64	SCREW M6X30	2
68	17-68	SMALL BEALING	1
69	16-69	LARGE BEALING	1
72	16-72	PIN 2X15.8	59
73	16-73	DOWEL PIN 3x10	3
78	16-78	ROLL PIN 6X16	2
80	16-80	WASHER	2
82	16-82	STRAP GUIDE PAWL, 15 – 20	1
83	16-83	STRAP GUIDE, FRONT, 15 – 20	1
84	17-84	REATING WIRE	1
86	17-86	STRAP GUIDE, REAR, 15 - 20	1
100	17-100	SEALING HANDLE	1